

# Awning Centre Support Cradle

## An Installation Guide

LAST UPDATED 22.11.23

# 1.

Find a suitable location on your van for the support cradle. Mark the 6 screw holes with a pencil to help you install the support.



# 2.

Drill holes and install the four screws of the back plane.



# 3.

Drill holes and install the two screws for the bracket.



# 4.

Install the cradle with provided screws and tighten.



Disclaimer: Supex assumes no liability for damages or injuries resulting from installation or operation of this product. Supex reserves the right to modify appearances and specifications without notice. Supex Products provides a one year warranty, however damages due to incorrect installation or product misuse are excluded.

# supex

Watch Video

