

Secura Bar

Installation Instructions

1. Prepare the awning: Ensure it is rolled out and lock the awning so the roller is at 3 o'clock.
2. Take out the Secura Bar from carton. The two bars will include the joiner piece fitted for packing purposes. By removing the 2 set screws, the joiner piece will slide out. Take out and reverse the direction, once complete, re-fix in place using the original set screws.
3. Release the locking cam handles, also ensure the top clamp section of the Secura Bar is in the open position. Slide the two sections together.
4. The bracket needs to be attached to the side of van at approx. 15mm underneath the underside of roof fabric and approx. 20mm from the edge of fabric to centre of bracket. Secondly, a 10mm / 3/8" hole must be drilled into roller tube approx. 20mm from edge of fabric and 15mm down from fabric.
5. The clip end can now be fixed into the wall bracket on the side of van. The top clamp section of the Secura Bar has to be in the open position. Lift up the bar until the it rests under the fabric of the awning. Extend fully out until the spigot falls into the place where the hole is, in the roller. The Secura Bar is now fully extended. Tighten the adjusting knob.
6. The fabric must be held in position on top of the Secura Bar. This is the break in the middle of the two sections. Hold with one hand and tighten the locking cam handles with the other hand.
7. Two sections of the Secura Bar should now be secured by the fabric.

